

# INDEX


## Page

<a href="#">501-E01_CYLINDER, HEAD AND COVER</a>	3
<a href="#">501-E02_PISTON/CRANKSHAFT</a>	5
<a href="#">501-E03_INTAKE/ESHAUST</a>	7
<a href="#">501-E04_WATER PUMP</a>	11
<a href="#">501-E05_OIL PUMP</a>	13
<a href="#">501-E06_OIL SYSTEM</a>	15
<a href="#">501-E07_CARBURETOR</a>	17
<a href="#">501-E08_CRANKCASE</a>	21
<a href="#">501-E09_MAGNETO</a>	25
<a href="#">501-E10_LEFT CRANKCASE COVER</a>	27
<a href="#">501-E11_SPROCKET</a>	29
<a href="#">501-E12_CLUTCH</a>	31
<a href="#">501-E13_CLUTCH</a>	37
<a href="#">501-E14_STARTING MOTOR</a>	39
<a href="#">501-F01_AIR CLEANER &amp; OIL TANK</a>	41
<a href="#">501-F02A_MUFFLER</a>	45
<a href="#">501-F03_FRAME BODY</a>	47
<a href="#">501-F04B_ARM</a>	51
<a href="#">501-F05_BODY COVER, SEAT</a>	53
<a href="#">501-F06_FUEL TANK</a>	57
<a href="#">501-F07B_SWING ARM SUB ASS'Y</a>	59
<a href="#">302-F08_WHEEL FRONT &amp; REAR</a>	63
<a href="#">501-F09_BRAKE CALIPER</a>	65
<a href="#">501-F10B_BRAKE SYSTEM</a>	67
<a href="#">501-F11B_HANDLE BAR</a>	69
<a href="#">501-F13B_STEERING</a>	71
<a href="#">501-F14A_BATTERY &amp; MAIN WARNESSE ASS'Y</a>	73
<a href="#">501-F15A_SIGNAL LIGHT, TAIL LIGHT</a>	75
<a href="#">501-F16A_STICKER</a>	77
<a href="#">501-F18_COOLING SYSTEM</a>	79
<a href="#">501-C03_ACCESSORY</a>	81

---

---

501-E01 Cylinder, head and cover




501-E01

## Cylinder head and cover

Item	Parts No.	Qt'y	Parts Name	
1	283-12401-11	1	CYLINDER	
2	031-51500-10	2	DOWEL PIN	13.1*14.7*18
3	283-15201-13	1	CYLINDER GASKET	
4	283-13003-10	1	CYLINDER HEAD	Incl.5~11
5	283-14202-03	4	VALVE GUIDE	
6	010-50804-01	4	STUD BOLT	M8*1.5
8	980-40081-10	2	DOWEL PIN	8*10
9	96000-06040-08B	8	HEX FLANGE BOLT	6*40
10	283-16001-03	2	SEAL INTAKE VALVE	
11	283-15901-03	2	SEAL VALVE	
12	283-15102-11	1	CYLINDER HEAD GASKET	
13	283-36301-03	1	CYLINDER HEAD COVER	
14	283-36101-13	1	CYLINDER HEAD COVER GASKET	
15	283-36001-03	4	RUBBER WASHER	10*19*5
16	283-16201-03	4	BOLT AND WASHER ASSY	
18	283-36201-13	4	LADDER BOLT	M6*14
21	283-65001-01	1	INTAKE MANIFOLD	
22	91000-08020K	2	HEX SOCKET BOLT	8*20
23	283-65901-00	1	CARBURETOR CLIP	Incl.24
24	93500-04030	1	HEX PHILLIPS BOLT	4*30
25	283-36901-01	2	EXHAUST PIPE GASKET	
26	017-20800-20	4	HEX NUT	M8*1.5
27	94111-0814020	4	SPRING WASHER	8*14*2

501-E02 piston /crankshaft




501-E02

## PISTON/CRANKSHAFT

Item	Parts No.	Qt'y	Parts Name	
1	283-20301-00	1	CRANK SHAFT ASS'Y	
2	283-35202-03	1	TIMING SPROCKET	
3	283-25003-03	1	PRIMARY DRIVE GEAR	
4	017-01800-50	1	HEX NUT	M18
5	020-01800-40	1	PLANE WASHER	
6	283-26001-23	1	SPACER (96401-3155085)	30.7*55*8.5
7	283-23403-07	1	PISTON	Incl.10
8	283-23302-03	1	PISTON PIN	
9	283-23501-17	1	PISTON RING SET	
10	056-52300-20	2	CLIP PISTON PIN	
11	283-24105-01	1	BALANCER SHAFT	
12	032-30400-70	1	SEMICYCLE KEY	
13	94050-14000C	1	HEX FLANGE NUT WITH SERRATED	14mm
14	020-01400-30	1	PLAIN WASHER	14*30*4.5
15	283-76201-03	1	SPRAG CLUTCH	30*34.5*26

501-E03 INTAKE / EXHAUST




501-E03

INTAKE/EXHAUST

Item	Parts No.	Qt'y	Parts Name	
1	283-31601-11	1	CAMSHAFT (IN)COMP	
2	283-31602-21	1	CAMSHAFT (EX)COMP	
3	283-35601-03	2	STOPPER PLATE	
4	283-33401-13	2	IN. VALVE	
5	283-33502-03	2	EXKAUST VALVE	
6	283-33701-03	4	VALVE SPRING RETAINER	
7	132-10AA0-20	8	VALVE COTTER	
8	283-35701-03	4	VALVE SEAT	
9	283-35801-03	4	VALVE LIFTER	
10	283-35901-03	4	ADJSTING PAD	T=1.450
	283-35902-03	4	ADJSTING PAD	T=1.500
	283-35903-03	4	ADJSTING PAD	T=1.550
	283-35904-03	4	ADJSTING PAD	T=1.600
	283-35905-03	4	ADJSTING PAD	T=1.625
	283-35906-03	4	ADJSTING PAD	T=1.650
	283-35907-03	4	ADJSTING PAD	T=1.675
	283-35908-03	4	ADJSTING PAD	T=1.700
	283-35909-03	4	ADJSTING PAD	T=1.725
	283-35910-03	4	ADJSTING PAD	T=1.750
	283-35911-03	4	ADJSTING PAD	T=1.775
	283-35912-03	4	ADJSTING PAD	T=1.800
	283-35913-03	4	ADJSTING PAD	T=1.825
	283-35914-03	4	ADJSTING PAD	T=1.850
	283-35915-03	4	ADJSTING PAD	T=1.875
	283-35916-03	4	ADJSTING PAD	T=1.900
	283-35917-03	4	ADJSTING PAD	T=1.925
	283-35918-03	4	ADJSTING PAD	T=1.950
	283-35919-03	4	ADJSTING PAD	T=1.975
	283-35920-03	4	ADJSTING PAD	T=2.000
	283-35921-03	4	ADJSTING PAD	T=2.025

501-E03 INTAKE / EXHAUST




501-E03

## INTAKE/EXHAUST

Item	Parts No.	Qt'y	Parts Name	
	283-35922-03	4	ADJSTING PAD	T=2.050
	283-35923-03	4	ADJSTING PAD	T=2.075
	283-35924-03	4	ADJSTING PAD	T=2.100
	283-35925-03	4	ADJSTING PAD	T=2.125
	283-35926-03	4	ADJSTING PAD	T=2.150
	283-35927-03	4	ADJSTING PAD	T=2.200
	283-35928-03	4	ADJSTING PAD	T=2.250
	283-35929-03	4	ADJSTING PAD	T=2.300
11	283-33601-03	4	VALVE OUTER SPRING	
12	283-33602-03	4	VALVE INNER SPRING	
13	283-37001-03	1	CAM CHAIN	
14	283-37102-03	1	GUIDE COMP CAM CHAIN	
15	283-37201-03	1	CHAIN GUIDE	
16	283-37303-01	1	CAM CHAIN TENSIONER	
17	283-36401-00	1	TENSIONER LIFTER	
18	283-36801-03	1	GASKET,TENSIONER LIFTER	
19	96000-06008-10K	1	HEX FLANGE BOLT	6*8
20	021-10600-20	1	PLAIN WASHER	
21	283-37401-03	1	PIVOT,CAM CHAIN TENSIONER	
22	96000-06025-08B	2	HEX FLANGE BOLT	6*25

501-E04 Water Pump




501-E04

WATER PUMP

Item	Parts No.	Qt'y	Parts Name	
1	283-55102-13	1	WATER PUMP IMPELLER	
2	021-80600-10	1	WATER PUMP OIL SEAL	
3	283-55202-01	1	WATER PUMP COVER	
4	283-55602-13	1	WATER PUMP COVER GASKET	
5	283-56101-01	1	THERMOSTAT WITH GASKET	
6	283-55301-03	1	THERMOSTAT COVER	
7	257-56002-01	1	THERMO SWITCH COMPL	
8	96000-06025-08B	7	HEX FLANGE BOLT	6*25
9	94103-0612010	1	SEALING WASHER	6.5*12*1
10	96000-06020-08C	2	HEX WASHER FACE BOLT	6*20

501-E05 Oil and Fuel Pump




501-E05

## OIL PUMP

Item	Parts No.	Qt'y	Parts Name	
1	283-65102-00	1	OIL PUMP ASS'Y	Incl.2~9
	283-65101-03	1	OIL PUMP CASE 1	
2	283-65202-03	1	OIL PUMP CASE 2	
3	283-66102-03	1	INNER ROTOR(FEED)	
4	283-66202-03	1	OUTER ROTOR(FEED)	
5	283-66301-03	1	INNER ROTOR(SCAV)	
6	283-66401-03	1	OUTER ROTOR(SCAV)	
7	283-65302-03	1	OIL PUMP SHAFT	
8	031-00300-30	2	DOWEL PIN	
9	031-00300-40	2	DOWEL PIN	
10	283-64104-03	1	OIL PUMP DRIVE GEAR	
11	94511-1200S	1	EXTERNAL CIR CLIP	STW-12
12	283-65801-02	1	OIL SIEVE	
13	96000-06030-08B	3	HEX FLANGE BOLT	6*30
14	257-62203-00	1	PUMP, GASOLINE	

501-E06 OIL SYSTEM




501-E06

## OIL SYSTEM

Item	Parts No.	Qt'y	Parts Name	
1	15412-169-000	1	OIL FILTER ELEMENT	
2	283-65501-00	1	OIL FILTER COVER	inci.3
3	X40-31400-10	1	PLUG	
4	283-67501-03	1	OIL RING	
5	283-66501-00	1	PRESSURE RETAINER VALVE HOUSING	
6	283-66601-03	1	COMPERSION SPRING	
7	283-66701-03	1	PLUG SCREW	
8	021-11100-10	1	AL PLAIN WASHER	11*19*1
9	283-65401-03	1	OIL FILTER ELEMENT SETTING SPRING	
10	283-68002-10	1	OIL PIPE(15201-501-000)	
11	053-01200-41	3	OIL BOLT	
12	94103-1220015	6	COPPER PLAIN WASHER	12.5*20*1.5
13	96000-06065-08B	1	HEX WASHER FACE BOLT	6*65
14	96000-06025-08B	2	HEX FLANGE BOLT	6*25

501-E07 CARBURETOR




501-E07

## CARBURETOR

Item	Parts No.	Qt'y	Parts Name	
1	20H-62301-00	1	CARBURETOR ASS'Y	Incl2~50
2	283-62535-08	1	THROTTLE VALVE(#105)	
3	165-62359-08	1	"E"RING	
4	164-62391-08	1	"O" RING	
5	283-62350-08	1	HOLDER	
6	283-62345-08	1	SPRING	
7	283-62351-08	1	DIAPHRAGM	
8	283-62352-08	1	PISTON VALVE	
9	283-62346-08	1	SPRING	
10	283-62353-08	1	WASHER	
11	260-62355-08	1	RING	
12	283-62354-08	1	WASHER	
13	283-62305-08	1	JET NEEDLE	
14	283-62355-08	1	DIAPHRAGM COVER	
15	212-62361-08	2	SCREW	
16	230-62402-08	1	JET(#42.5)	
17	113-62303-08	1	MAIN JET(#150)	
18	283-62358-08	1	RING	
19	283-62359-08	1	JET HOLDER	
20	164-62395-08	1	"O"RING	
21	283-62505-08	1	FLOAT-A	
22	209-62354-08	1	SCREW	
23	110-62515-08	1	PIN	
24	290-62351-08	1	FLOAT BODY	
25	283-62361-08	1	SCREW	
26	283-62362-08	1	"O"RING	
27	283-62501-08	1	NEEDLE VALVE	
28	283-62300-08	1	NEEDLE JET	
29	266-62409-08	1	JET(#110)	
30	283-62363-08	1	JET(#120)	

501-E07 CARBURETOR




501-E07

## CARBURETOR

Item	Parts No.	Qt'y	Parts Name	
31	257-62364-08	1	SCREW	
32	257-62373-08	1	PLUNGER ASSY	
33	283-62364-08	1	GUIDE HOLDER	
35	106-62460-08	1	SPRING	
36	106-62384-08	1	"O"RING	
37	283-62420-08	1	PILOT JET(#45)	
38	283-62365-08	1	COVER A	
39	130-62372-08	2	SCREW	
40	283-62347-08	1	SPRING	
41	283-62366-08	1	DIAPHRAGM ASSY	
42	283-62367-08	4	SCREW	
43	109-62446-08	1	SPRING	
44	283-62368-08	1	FILTER	
45	248-62410-08	1	AIR JET	
46	283-62369-08	1	ADJUST SCREW	
47	257-62353-08	1	CABLE GUIDE	
48	226-62354-08	3	SCREW	
49	260-62365-08	1	COVER	
50	260-62364-08	1	"O"RING	
51	94400-0408430	1	HOSE	
52	94400-0609300	2	HOSE	6*9*300
53	94513-08000	1	SPRING CLAMP	
54	94510-09000	2	CLIP	9*1

501-E08 Crankcase




501-E08

## CRANKCASE

Item	Parts No.	Qt'y	Parts Name	
1	290-10301-20	1	CRANKCASE ASS'Y	Incl.2~23,30~40
2	235-15421-03	1	BLIND PLUG	
3	044-02500-70	1	OIL SEAL	25*38*7
4	061-02500-10	1	NEEDLE BEARING	NTN
5	044-01200-30	2	OIL SEAL	12*18*5
6	044-01300-20	1	OIL SEAL	13*22*5
7	060-02001-50	1	RADIAL BALL BEARING	6004
8	060-02501-10	1	RADIAL BALL BEARING	
9	061-01300-01	1	NEEDLE BEARING	NTN
10	060-21200-11	1	BEARING (RELEASE)	
11	060-02501-20	1	RADIAL BALL BEARING	
12	060-02001-20	1	RADIAL BALL BEARING	6204C3
13	060-03502-21	1	RADIAL BALL BEARING	X50CM40 (TMB)
14	060-03502-21	1	RADIAL BALL BEARING	X50CM40 (TMB)
16	060-02501-70	1	RADIAL BALL BEARING	
17	060-02501-70	1	RADIAL BALL BEARING	
18	031-00600-10	4	DOWEL PIN	6*10
19	031-00600-10	4	DOWEL PIN	6*10
20	283-16401-03	1	COLLAR	
21	283-16401-03	1	COLLAR	
22	060-02501-30	1	RADIAL BALL BEARING	
23	283-8C601-03	1	STOPPER PIN	
30	283-55002-01	1	WATER PUMP SHAFT	Incl.31,32
31	060-01200-60	1	BALL BEARING	
32	006-26100-90	1	"O" RING	
33	257-56201-01	1	MECHANICAL SEAL COMPL.	
34	081-01000-30	1	BREATHER PIPE	
35	283-15503-03	1	STOPPER PLATE	t=3.2
36	96000-06020-08C	1	HEX WASHER FACE BOLT	6*20
37	283-15504-03	2	STOPPER PLATE	t=2.0

501-E08 Crankcase




501-E08

CRANKCASE

Item	Parts No.	Qt'y	Parts Name	
38	96000-06012-08C	2	HEX WASHER FACE BOLT	6*12
39	96000-06040-08B	7	HEX FLANGE BOLT	6*40
40	96000-06075-08B	8	HEX WASHER FACE BOLT	6*75
41	283-69301-23	1	MAGNETIC DRAIN PLUG	M12*1.5
42	94104-1320020	1	PLAIN WASHER	12.5*20*2
43	031-51500-10	2	DOWEL PIN	13.1*14.7*18

501-E09 MAGNETO / STARTING MOTOR




0,00 0,00

501-E09

MAGNETO

Item	Parts No.	Qt'y	Parts Name
1	283-70101-01	1	GENERATOR FLYWHEEL
2	283-75005-10	1	STATOR COMP
3	283-75602-00	1	STARTER CLUTCH ASS'Y
4	283-75501-03	1	FREE WHEEL GEAR 67 ASS'Y
5	91000-06018K	8	HEX SOCKET BOLT 6*18
6	065-01407-60	1	SPARK PLUG
7	283-72202-01	1	C.D.I UNIT
8	283-71201-01	1	HIGH TENSION COIL
9	283-76301-03	1	SPARK PLUG CAP

501-E10 Left Crankcase Cover




501-E10

## LEFT CRANKCASE COVER

Item	Parts No.	Qt'y	Parts Name	
1	290-71702-00	1	L. CRANK CASE COVER	Incl.2~5
2	283-77101-03	1	A.C.G. CAP 1	
3	283-77201-03	1	A.C.G. CAP 2	
4	024-02700-40	1	O-RING	28*2.4
5	024-01200-10	1	O-RING	12.5*2.4
6	91000-05030C	3	HEX SOCKET BOLT(BK)	M5*30
7	96000-05012-08K	2	HEX BOLT	5*12
8	283-75001-13	1	L COVER GASKET	
9	96000-06035-08B	11	HEX WASHER FACE BOLT	6*35
10	283-75101-03	1	STARTER REDUCTION GEAR COMP	
11	283-75201-13	1	SHAFT1	
12	283-75301-03	1	STARTER REDUCTION SHAFT COMP.	
13	283-75401-13	1	STARTER REDUCTION GEAR SHAFT	

501-E11 SPROCKET



501-E11

SPROCKET

Item	Parts No.	Qt'y	Parts Name	
1	283-89603-03	1	DRIVE SPROCKET	
2	283-89702-03	1	DRIVE SPROCKET FIXING PLATE	
3	24700-501-000	1	GEAR CHANGE PEDAL ASS'Y	
4	91000-06025B	1	HEX SOCKET BOLT	6*25
5	96000-06012-08B	2	HEX FLANGE BOLT	6*12
6	283-89503-03	1	CHAIN GUIDE	



501-E12

2 CLUTCH

Item	Parts No.	Qt'y	Parts Name	
1	283-86202-00	1	MAIN SHAFT ASS'Y	Incl.2~11
2	283-82208-03	1	M-2 GEAR	
3	283-82212-03	1	M-4 GEAR	
4	283-82213-03	1	M-5 GEAR	
5	283-82211-03	1	REVERSE GEAR(DRIVE)	
6	283-86406-03	1	COLLAR	
7	283-86405-03	1	COLLAR	
8	283-86701-03	1	SPLINE WASHER	
9	283-86802-03	1	THRUST WASHER	
10	283-86901-03	1	CLIP	
11	283-86804-03	2	THRUST WASHER	
20	283-87002-00	1	COUNTER SHAFT ASS'Y	Incl.21~36
	283-87002-01	1	COUNTER SHAFT COMPL	
21	283-82106-03	1	GEAR COMP	
22	283-82107-03	1	C-2 GEAR	
23	283-82108-03	1	C-3 GEAR	
24	283-82109-03	1	C-4 GEAR	
25	283-82110-03	1	C-5 GEAR	
26	283-82111-03	1	COUNTERSHAFT REVERSE GEAR	
27	283-86403-03	1	REVERSE GEAR BUSH	
28	283-86409-03	1	COLLAR	
29	283-86405-03	1	COLLAR	
30	283-86407-03	1	COLLAR(SPLINE)	
31	283-86803-03	2	WASHER	
32	283-87402-03	3	WASHER	
33	283-86701-03	1	SPLINE WASHER	
34	283-86801-03	1	WASHER	
35	283-86702-03	1	LOCK WASHER	
36	283-86901-03	1	CLIP	
40	283-87612-01	1	SHIFT DRUM	Incl.41




501-E12

2 CLUTCH

Item	Parts No.	Qt'y	Parts Name	
41	283-87801-03	1	COLLER	4*8
42	283-87702-03	1	GEAR SHIFT CAM	
43	283-8B001-03	1	SHIFTER PIN	
44	283-8B102-03	1	DRUM SHIFTER	
45	283-8B201-03	1	SHIFTER COLLAR	
46	283-8B301-03	1	RATCHET PAWL A	
47	283-8B401-03	1	RATCHET PAWL B	
48	283-8B501-03	2	PLUNGER	
49	283-8B601-03	2	PLUNGER SPRING	
50	283-8B701-13	1	GUIDE PLATE	
51	96000-06020-10C	2	HEX FLANGE BOLT	M6*20
52	283-8C301-01	1	GEAR SHIFT DRUM STOPPER COMP	
53	283-88005-13	1	SHIFT DRUM STOPPER SPRING	
54	283-88101-03	1	ROLLER	3.8*6.9
55	283-88201-03	1	SPRING(POINT)	
56	283-89906-03	1	LADDER BOLT	6*16*4.5
57	283-88410-03	1	GEAR SHIFT FORK	
58	283-88411-03	1	L.GEAR SHIFT FORK	
59	283-88412-03	1	R.GEAR SHIFT FORK	
60	283-88506-03	1	SHIFT FORK GUIDE SHAFT	
61	283-88506-03	1	SHIFT FORK GUIDE SHAFT	
62	283-88601-03	2	SPRING	
70	283-8C002-11	1	SHIFT SHAFT ASS'Y	Incl.71,72
71	283-86902-03	1	SNAP RING	
72	283-8C201-03	1	GEAR SHIFT RETURN SPRING	
73	94101-1421010	1	PLAIN WASHER	13.8*20.9*1
80	283-89304-00	1	NEUTRAL SWITCH CONTACT ASS'	Incl.81
81	024-02100-10	1	OIL RING	20.8*2.5
82	013-10500-30	2	PANPHILLIPS BOLT	5*20
90	283-8A001-01	1	REVERSE IDLE GEAR ASS'Y	Incl.91~94
91	283-87801-03	1	COLLER	4*8

# 501-E12 CLUTCH




501-E12

2 CLUTCH

Item	Parts No.	Qt'y	Parts Name	
92	94105-1624010	1	PLAIN WASHER	16*24*1.0
93	283-8A101-03	1	REVERSE SHAFT COMPL.	
94	283-86408-03	1	REVERSE IDLE GEAR BUSH	
95	283-8A201-01	1	GEAR SHIFT SPINDLE COMP	
96	283-8A401-03	1	REVERSE SHIFT DRUM STOPPER SPRING	
97	283-8A301-03	1	REVERSE SHIFT STOPPER COMP	
98	94511-1200S	1	EXTERNAL CIR CLIP	STW-12
99	94101-1227010	1	PLAIN WASHER	12*27*1.0
100	96000-06012-08B	1	HEX FLANGE BOLT	6*12

501-E13 CLUTCH




501-E13

1 CLUTCH

Item	Parts No.	Unit Q'ty	Parts Name	
1	290-85004-01	1	RIGHT CRANKCASE COVER	Incl.2~4
2	283-85101-03	1	OIL SEAL(CRANK)22811-501-000	
3	003-14260-00	1	SNAP RING, INNER	
4	271-38201-01	1	PIPE COMPL.	
5	283-85302-03	1	R.CRANKCASE COVER GASKET(11393-501-000)	
7	283-83903-00	1	CLUTCH ASS'Y (22100-501-000)	Incl.8~17
	283-83914-08	1	OUTER COMPL,CLUTCH (22110-501-000)	
8	91000-06025B	6	HEX SOCKET BOLT	6*25
9	283-83905-08	6	FORMED WASHER	6*20*1.6
10	283-83904-08	6	SPRING CLUTCH	
11	283-83909-08	1	DISK,CLUTCH PRESSURE(22350-501-000)	
12	283-83910-08	1	RADIAL BALL BEARING	6001
13	283-83902-18	1	CENTER COMPL,CLUTCH(22121-501-000)	
14	283-83915-08	7	CLUTCH FRICTION DISK	
15	283-83908-08	7	CLUTCH PLATE	
16	283-83907-08	1	DISK B,CLUTCH FRICTION	
17	283-83913-08	1	PLAIN WASHER	22*42*2.5
18	283-85502-03	1	DISTANCE COLLAR	
19	283-85601-01	1	CLUTCH LEVER COMP.	
20	283-85701-03	1	CLUTCH LEVER SPRING	
21	283-85802-03	1	CLUTCH LIFTER GUIDE PIN	
22	283-85901-03	1	CLUTCH LIFTER ROD	
23	283-86102-03	1	PLATE(RELEASE SHAFT)	
24	011-00602-30	1	HEX WASHER FACE BOLT	6*20
25	980-26180-10	1	LOCK NUT	M18
26	980-35180-20	1	DISC SPRING WASHER	18.5*30*2.3
27	96000-06025-08B	11	HEX FLANGE BOLT	6*25

501-E14 STARTING MOTOR



501-E14

STARTING MOTOR

Item	Parts No.	Unit	Qt'y	Parts Name	
1	283-70501-00	1		STARTING MOTOR ASS'Y	Incl.2~11
	257-70501-08	1		FRONT BRACKET ASSY	Incl.2
2	164-70553-08	1		"O"RING	
3	155-70572-08	2		RUBBER RING	
5	257-70550-08	1		WASHER SET	
6	257-70551-08	2		SET BOLT ASSY	
7	155-70575-08	3		"O"RING	
8	94050-06000B	1		HEX FLANGE NUT	6mm
9	283-70505-08	1		REAR BRACKET ASSY	
10	257-70552-08	1		ARMATURE ASSY	
11	155-70573-08	1		CARBON BRUSH SET	
12	96000-06025-08B	2		HEX FLANGE BOLT	6*25



501-F01

AIR CLEANER &amp; SECOND

ARY OIL TANK

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	17200-501-000	1	AIR CLEANER ASS'Y	
2	17206-501-000	1	AIR CLEANER CASE	
3	94516-74000	1	CLAMP	
4	17207-501-000	1	CLEANER CASE CAP	
5	17255-501-000	1	CLAMP	#46
6	94103-131820	2	COPPER PLAIN WASHER	13*18*2
7	17284-501-000	1	REAR L.AIR CLEANER BRACKET	
8	92003-06015K	2	HEX BOLT(TRIANGE)	6*15
9	96000-06012-08G	4	HEX WASHER FACE BOLT	6*12
10	55124-501-000	1	OIL FILTER SCREEN BOLT	
11	55123-501-000	2	GROMMET	
12	90111-06011-10G	2	LADDER BOLT	6*11*6
13	55110-501-000	1	OIL TANK ASS'Y	
14	96000-06010-08B	2	HEX FLANGE BOLT	6*10
15	55112-501-000	1	OIL SUCTION HOSE ASS'Y	
16	55111-501-000	1	OIL RETURN HOSE ASS'Y	
17	55113-501-000	1	BREATHER HOUSE	
18	15650-501-000	1	OIL LEVEL GAUGE	
19	11131-179-000	1	MAGNETIC DRAIN PLUG(COLOR)	M12*1.5
20	94513-16000	4	SPRING CLAMP	16mm
21	96000-06035-10B	2	HEX FLANGE BOLT	6*35
22	94513-17000	2	SPRING CLAMP	17.8mm
23	77211-145-001	1	RUBBER	
24	17253-501-000	1	VENT HOSE	
25	17281-501-000	1	FRONT R.AIR CLEANER BRACKET	
26	17282-501-000	1	FRONT L.AIR CLEANER BRACKET	
27	17283-501-000	1	REAR L.AIR CLEANER BRACKET	
28	17213-501-000	1	SEAL OIL CLEANER COVER	
29	91312-501-000	2	OIL RING	12*19*3.5
30	94104-1320020	1	PLAIN WASHER	12.5*20*2




501-F01

AIR CLEANER & SECOND

ARY OIL TANK

Item No.	Parts No.	Unit Q'ty	Parts Name	
31	17210-501-000	1	CLEANER FILTER NET	
32	94516-91000	1	CLAMP	
33	17228-501-000	1	SPONGE A	
34	17229-501-000	1	SPONGE B	
35	91316-179-000	1	OIL RING	16*2.5
36	94400-1218230	1	HOSE	
37	90350-06000G	2	NYLON NUT	M6
38	96401-0610019	2	SPACE TUBE	6.5*9.5*19
39	94101-0618020B	2	PLAIN WASHER	6*18*2
40	91318-108-000	1	OIL RING	18*3

501-F02A MUFFLER




501-F02A

(EU2) MUFFLER

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	94102-0615010	2	PAPER PLATE WASHER	6*15*1.0
2	94513-18000	2	SPRING CLAMP	18mm
3	18300-501-00C	1	EXHAUST PIPE ASS'Y	
4	18311-501-00A	1	EXHAUST PIPE OF FRONT SECTION	
5	18321-501-00A	1	SILENCER MUFFLER	
6	18301-501-000	1	PROTECTOR COMP MUFFLER	
7	18308-501-000	1	PIPE GASKET	
8	18302-501-000	1	MUFFLER CLAMP	
9	17411-501-000	1	REED VALVE COMP IN. PIPE	50mm
10	94513-16000	1	SPRING CLAMP	16mm
11	93701-06012S	2	PAN FLAT HEAD PHILLIPS BOLT	6*12
12	96000-10040-14G	1	HEX FLANGE BOLT	M10*40
13	17410-116-000	1	REED VALVE COMP	
14	92006-06016-10G	2	HEX WASHER FACE BOLT	6*16
15	17412-501-000	1	REED VALVE COMP EX. PIPE	470mm
16	18314-501-000	1	ISOLATION GASKET	

501-F03 FRAME BODY




501-F03

## FRAME BODY

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	61104-501-000	1	R. BRACKET FOR FRONT FENDER	
2	83431-501-001	1	REAR COVER LOWER R.SUP.	
3	94101-1225050C	2	PLAIN WASHER	12*25*5
4	64309-501-000	1	FRONT COVER FIXED POLE	
5	96000-10020-14B	6	HEX WASHER FACE BOLT	10*20
6	96000-06016-10G	6	HEX FLANGE BOLT	6*16
7	50717-182-00A	1	R.STEP BAR COMP	
8	50718-182-00A	1	L.STEP BAR COMP	
9	64341-225-000	1	FRONT COVER LEFT FIXED POLE	
10	64342-225-000	1	FRONT COVER RIGHT FIXED POLE	
11	54325-901-000	1	REAR ENG MT BRACKET(LOWER)	
12	64509-501-000	2	FOOLD PANEL SPACE	
13	83432-501-001	1	REAR COVER LOWER R.SUP.	
14	94101-0822015B	2	PLAIN WASHER	8*22*1.5
15	77212-169-000	2	RUBBER	
16	77211-145-001	2	RUBBER	
17	94101-1022020G	5	PLAIN WASHER	10*22*2
18	96000-10120-14G	5	HEX WASHER FACE BOLT	10*120
19	90350-10000Z	5	NYLON NUT	10mm*1.25
20	64358-501-000	4	LOOP FOR PROTECTION NET	
21	96000-10035-14G	3	HEX FLANGE BOLT	M10*35
22	96000-10015-14G	7	HEX FLANGE BOLT	M10*15
23	96000-06010-10K	4	HEX FLANGE BOLT	M6*10
24	52112-169-000	1	CHAIN ROLLER	14*22*22
25	52119-169-000	1	CHAIN ROLLER COLLER	8.2*14*25.5*3
26	96000-0803512CL	1	HEX WASHER FACE BOLT	8x35
27	290-90301-00	1	TOOL BAG	
28	96000-08016-12G	12	HEX WASHER FACE BOLT	8*16
29	83402-903-000	1	REAR COVER UP FIXED PLATE	
30	83403-903-000	1	REAR COVER UP RIGHT FIXED PLATE	


501-F03 FRAME BODY



501-F03

## FRAME BODY

Item No.	Parts No.	Unit Q'ty	Parts Name	
31	90350-10000B	31	NYLON NUT	10mm*1.25
32	80120-903-000	1	PLATE BRACKET	
33	64507-501-000	1	R. FOOLD PANEL BAR	
34	64508-501-000	1	L. FOOLD PANEL BAR	
35	42714-145-000	1	TIRE PRESSURE GAGE	
36	96000-06014-10G	8	HEX FLANGE BOLT	M6*14
37	33449-225-000	1	R.R. BLINKER BRACKET	
38	33461-225-000	1	R.L. BLINKER BRACKET	
39	64324-501-000	2	FOOLR PANEL NET	
40	61103-501-000	1	L. BRACKET FOR FRONT FENDER	
41	54486-501-000	1	IG COIL BEACKRT	
42	64307-501-000	1	FRONT COVER LEFT FIXED POLE	
43	64308-501-000	1	FRONT COVER RIGHT FIXED POLE	
44	50201-501-000	1	R.ENGINE FIXED PLATE	
45	50202-501-000	1	L.ENGINE FIXED PLATE	
46	94050-06000G	4	HEX FLANGE NUT WITH SERRATI	M6
47	64310-501-000	1	FLOOR PANEL(AL)	
48	96000-10045-14G	1	HEX WASHER FACE BOLT	10*45
49	94101-1222060G	1	PLAIN WASHER	12*22*6
50	64510-501-000	1	R.NURFBAR FIX BRACKET	
51	64511-501-000	1	L.NURFBAR FIX BRACKET	



501-F04B

ARM

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	51400-501-00B	2	FRONT CUSHION ASS`Y(NITROGE	373mm
2	96000-10050-14G	4	HEX FLANGE BOLT	M10*50
3	45452-197-000	2	BRAKE HOSE CLAMP	
4	90350-10000G	12	NYLON NUT	M10*P1.25
5	91312-169-00A	16	O-RING	12.5*2.4
6	44540-901-000	2	BALL JOINT	
7	94101-1222020G	4	PLAIN WASHER	12*22*2
8	94051-12000-17G	4	HEX,SLOTTED NUT	12mm
9	94201-30320B	4	COTTER PIN	3*32
10	51350-169-00A	8	BUSHING	10*17*44.5
11	96000-10065-14G	8	HEX FLANGE BOLT	M10*65
12	51202-169-000	16	BUSH	17*23.1*19.2
13	96000-06012-10G	2	HEX WASHER FACE BOLT	6*12
14	94001-16000	4	HEX NUT	16mm
15	94101-1020020G	10	COPPER PLAIN WASHER	10*20*2
16	44540-501-000	2	BALL JOINT	



FRONT

501-F05

BODY COVER,SEAT

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	81144-225-000	2	INNER BOX LID BRACKET	
2	93903-04012K	2	TAPPING SCREW TRUSS HEAD PH 4*12	
3	64325-225-000	1	LEFT SIGNAL LIGHT COVER	
4	64326-225-000	1	RIGHT SIGNAL LIGHT COVER	
5	93701-06015G	6	PAN FLAT HEAD PHILLIPS BOLT	6*15
6	64321-225-000	1	FRONT FASCIA	
7	64305-501-000	1	LEFT AIRING COVER	
8	64304-501-000	1	RIGHT AIRING COVER	
9	90663-179-000	11	PLASTIC BOLT	
10	64353-225-000	2	SCREEN NET	
11	93800-06015S	6	PAN PHILLIPS BOLT	6*15
12	94102-145-000	10	RUBBER WASHER	
13	90350-06000G	8	NYLON NUT	M6
14	93903-04016K	8	TAPPING SCREW TRUSS HEAD PH 4*16	
15	92000-06020-10K	4	HEX BOLT	6*20
16	94101-0618020B	6	PLAIN WASHER	6*18*2
17	61100-501-000	1	L.FRONT FENDER	
18	61101-501-000	1	R.FRONT FENDER	
19	83600-501-000	1	LEFT SIDE COVER	
20	83500-501-001	1	RIGHT BODY COVER	
21	33741-145-000	2	REFLECTOR	SAE JUTE 9823
22	83407-225-000	1	REAR COVER ISOLATION GASKET	
23	90662-261-000	4	RIVET	#4-6
24	80118-225-000	1	TAIL LIGHT BASE	
25	83420-225-000	1	R. R.COVER LSOLATION GASKET	
26	94101-0310010B	8	PLAIN WASHER	3.5*10*1
27	94101-0514010K	10	PLAIN WASHER	5*14*1
28	90669-168-000	6	CABLE TIE	3*150 m/m
29	64355-903-000	1	COVER	
30	35116-225-000	1	POWER SUPPLY	




FRONT

501-F05

BODY COVER,SEAT

Item No.	Parts No.	Unit Q'ty	Parts Name	
31	90344-0600A	12	U PLATE NUT	6mm
32	92003-06020K	2	HEX BOLT(TRIANGE)	6*20
33	93800-06020K	12	PAN PHILLIPS BOLT	6*20
34	94101-0615010B	2	PLAIN WASHER	6.5*15*1
35	64345-225-000	1	SIDE COVER ISOLATION GASKET	0.1+3MM/200°C
36	92006-06014-10G	2	HEX WASHER FACE BOLT	6*14

501-F06 FUEL TANK




501-F06

## FUEL TANK

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	17511-501-000	1	FUEL TANK ASS'Y	
2	17500-501-000	1	FUEL TANK COMP	
3	16953-501-000	1	FUEL COCK BODY	
4	16951-169-000	1	FUEL CUP RING	
5	16950-501-000	1	FUEL COCK ASS'Y	
6	96000-06012-08B	2	HEX FLANGE BOLT	6*12
7	96000-06020-10G	2	HEX FLANGE BOLT	M6*20
8	92006-06014-10G	2	HEX WASHER FACE BOLT	6*14
9	50129-501-000	1	FUEL PUMP BRACKET	
10	37800-225-000	1	PETROL GAUGE ASS'Y	
11	94701-3004140	1	SPONGE PAD	30*4*140
12	17504-272-000	1	FRONT COVER RUBBER GASKET	t=3
13	55101-169-000	1	ISOLATION PAD	
14	93000-05012C	4	ROUND PHILLIPS BOLT	5*12
15	94400-0408150	2	HOSE	4.8*8*150
16	94400-0510180	2	FUEL HOSE	5*10*180
17	94400-0510470	1	FUEL HOSE	5.3*10.5*470
18	96000-06010-10B	2	HEX WASHER FACE BOLT	6*10
19	94050-05000C	2	HEX FLANGE NUT WITH SERRATED	5mm
20	94513-09000	7	SPRING CLAMP	
21	16952-145-000	1	PETROL FILTER	
22	45453-501-000	1	JOINT	
23	94400-0408210	1	HOSE	4.8*8*L=210
24	94510-08000	6	CLIP	8*0.8
25	94510-09000	1	CLIP	9*1
26	90111-08008-12G	2	LADDER BOLT	
27	94102-1022020	2	RUBBER WASHER	10*20*2

501-F07B SWING ARM SUB ASS'Y




501-F07B

SWING ARM SUB

ASS'Y

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	52400-501-00A	1	REAR CUSHION ASS'Y(NITROGEN)	398mm
2	96000-1206517GL	1	HEX FLANGE BOLT	M12*65
3	96000-10055-14G	3	HEX WASHER FACE BOLT	10*55
4	90350-12000G	1	NYLON INSERT LOCK NUT	M12
5	96502-06000	2	GREASE VALEVE CAP	6mm
6	52116-501-002	1	SWING ARM BOLT	
7	52144-501-000	2	DUST SEAL	
8	52103-501-000	2	CUSHION	
9	52125-225-000	1	ROCKER ARM OF REAR CUSHION	
10	94050-15000B	1	HEX FLANGE NUT WITH SERRATI	15mm
11	40533-261-001	1	SHOE SLIDER	
12	94105-1022025G	6	PLAIN WASHER	10*22*2.5
13	92006-06020-10G	2	HEX WASHER FACE BOLT	6*20
14	94001-38150B	2	HEX NUT	M38*15*P1.5
15	93901-08018GL	3	HEX SOCKET FLAT HEAD BOLT	M8*18
16	42105-501-000	1	REAR BRAKE DISC	
17	42106-169-000	1	REAR BRAKE DISC FLANGE COMP.	
18	91340-169-000	2	O-RING	40*1.3
19	94511-7000S	1	EXTERNAL CIPCLIP	70
20	52120-169-000	1	REAR CALIPER STAY	
21	52102-169-000	2	O-SEAL	52*62*7/9
22	96100-6908LLU	3	BALL BEARING(6908 LLU/2AS)	6908LLU/AS
23	52113-501-000	1	REAR AXLE BUSH	
24	52126-501-000	1	AUXILIARY ROCKER ARM(REV.1)	
25	93901-10027G	4	HEX SOCKET FLAT HEAD BOLT	M10*27
26	23802-501-000	1	DRIVE SPROCKET	42T
27	42610-169-000	1	REAR SPROCKET FLANGE	
28	90350-10000G	10	NYLON NUT	M10*P1.25
29	42100-169-000	1	EXTERNAL CIRCLIP	
30	96000-08016-12G	3	HEX WASHER FACE BOLT	8*16

501-F07B SWING ARM SUB ASS'Y




501-F07B

SWING ARM SUB

ASS'Y

Item No.	Parts No.	Unit Q'ty	Parts Name	
31	52114-501-000	2	DUST SEAL	
32	40530-261-000	1	DRIVE CHAIN ASS'Y	520*96目
33	52128-501-000	1	INNER BUSHING R.	
34	96500-25325	4	OIL SEAL	25*32*5
35	96000-10080-14G	1	HEX FLANGE BOLT	M10*80
36	52117-501-001	1	CHAIN COVER	
37	40517-501-000	1	FRONT CHAIN PROTECTOR	
38	96000-06045-10B	2	HEX FLANGE BOLT	6*45
39	96000-10090-14G	2	HEX FLANGE BOLT	M10*90
40	42301-501-00A	1	REAR WHEEL AXLE	
41	94105-1529030G	1	PLAIN WASHER	15*29*3
42	94050-12000C	1	HEX FLANGE NUT WITH SERRATED	12mm
43	52200-501-000	1	REAR AXLE HOLDER	
44	96500-20265	2	O-SEAL	20*26*5
45	96401-1020034	1	BUSHING	10.2*20*34
46	96200-202620	1	NEEDLE BEARING	20*26*20
47	96200-253226	2	NEEDLE BEARING	BK 25*32*26
48	90350-06000G	4	NYLON NUT	M6
49	52119-501-000	1	INNER BUSHING L.	
50	94111-1017025G	4	SPRING WASHER	10*17*2.5
51	96501-06000	2	GREASE VALVE	6mm X 5
52	94516-48000	2	CLAMP	
53	40547-501-000	1	CHAIN GUIDE	
54	93701-06015G	4	PAN FLAT HEAD PHILLIPS BOLT	6*15
55	94101-0618020B	4	PLAIN WASHER	6*18*2
56	94101-0818035B	1	PLAIN WASHER	
57	94101-1225050C	2	PLAIN WASHER	12*25*5
58	90350-08000G	1	NYLON NUT	M8

302-F08 WHEEL FRONT & REAR





302-F08

## WHEEL FRONT &amp; REAR

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	42711-302-000	4	TIRE	185/55-14
2	87751-302-000	4	ADLY LOGO	55
	87751-302-00A	4	TOPRIMS LOGO	55
3	42701-302-000	2	WHELL COMP(AL)	14*7
4	42801-302-000	2	REAR RIM(AL)	14*7
5	96005-10035C	8	HUB STUD BOLT	10*35
6	42707-169-000	2	COLLAR	
7	96500-29435	4	OIL SEAL	29.3*43.6*4.5
8	96100-6004ZZ	4	RADIAL BALL BEARING	6004ZZCM/2A-T0
9	42037-256-000RD	2	REAR SHAFT HUB(RD)	
10	42705-169-000	2	COLLER	
11	42036-169-000RD	2	FRONT WHEEL HUB(RD)	
12	42616-145-000	4	AIR NOZZLE	
13	94001-10018B	16	WHEEL NUT	M10*18
14	94101-1840045C	4	PLANE WASHER	18*40*4.5
15	94201-30450B	4	COTTER PIN	3*45
16	94051-18000B	4	SCOTCH NUT	M18
17	42720-302-000	4	WHEEL HUB CAP	
18	94518-60000	4	CIRCLIP	60*1.9

501-F09 BRAKE CALIPER




↓  
FRONT

501-F09

BRAKE CALIPER

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	45000-256-000	1	R. FRONT BRAKE CALIPER ASS'Y	
2	45120-256-000	2	FRONT BRAKE PAD KIT	
3	45200-256-000	1	L. FRONT BRAKE CALIPER ASS'Y	
4	45015-169-000	2	BRAKE DISC	164mm
5	96000-0802012GL	4	HEX FLANGE BOLT	M8*20
6	93901-08018GL	8	HEX SOCKET FLAT HEAD BOLT	M8*18
7	43000-223-000	1	REAR BRAKE CALIPER ASS'Y	
8	43120-256-000	1	BRAKE PAD KIT	
9	96000-10028-14G	2	HEX WASHER FACE BOLT	10*28
10	45456-107-000	3	BRAKE HOSE FIX BOLT	10*22
11	94103-1015012	6	COPPER PLAIN WASHER	10*15*1.2

501-F10B BRAKE SYSTEM




501-F10B

## (EU2) BRAKE SYSTEM

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	46500-501-000	1	BRAKE PEDAL	
2	94511-1700S	1	EXTERNAL CIRCLIP	STW-17
3	94101-1731023B	1	PLAIN WASHER	17.6*31*2.3
4	91316-169-000	2	OIL RING	16.7*3.2
5	46501-501-000	1	RETURN SPRING	
6	43500-256-00A	1	REAR BRAKE CYLINDER SUB ASS'Y	
7	45456-107-000	5	BRAKE HOSE FIX BOLT	10*22
8	94103-1015012	10	COPPER PLAIN WASHER	10*15*1.2
9	45521-168-000	1	PIN	7mm
10	94251-912-000	1	LOCK PIN	8mm
11	96000-06016-10G	1	HEX FLANGE BOLT	6*16
12	45450-501-000	1	FRONT BRAKE HOSE ASS'Y	
13	43460-501-000	1	REAR BRAKE HOSE	
14	45502-256-000	1	BRAKE SHUNT ASS'Y	
15	45550-901-000	1	R. BRAKE HOSE	
16	96000-06035-10B	2	HEX FLANGE BOLT	6*35
17	90669-101-000	1	CABLE TIE	4.8*200 m/m
18	96000-06025-10C	2	HEX WASHER FACE BOLT	M6*25
19	45500-351-000	1	R. CYLINDER SUB ASS'Y	
20	35340-169-000	1	R.BRAKE SWITCH	
21	53186-601-000	1	PARKING BRAKE LEVER SET	
22	43482-501-000	1	PARKING BRAKE CABLE	
23	91000-06025B	2	HEX SOCKET BOLT	6*25
24	96000-08028-12G	2	HEX WASHER FACE BOLT	M8*28
25	53175-169-000	1	RIGHT LEVER	
26	53187-601-000	1	PARKING BRAKE LEVER	
27	43503-256-000	1	REAR MASTER CYLINDER GASKET	
28	53191-168-000	1	LOCK BLOT	
29	53192-168-000	1	LOCK NUT	

501-F11B HANDLE BAR



FRONT



501-F11B

(EU2) HANDLE BAR

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	53170-169-000	1	THROTTLE LEVER ASS'Y	
2	17910-501-000	1	THROTTLE CABLE	
3	53103-302-000	2	RIGHT HANDLE BAR CLAMP	
4	91000-06050C	1	HEX SOCKET BOLT	6*50
5	53101-302-000	2	HANDLE BAR BOTTOM CLAMP	
6	50137-501-000	1	REVERSE SWITCH SUPPORT	
7	96000-10028-14G	2	HEX WASHER FACE BOLT	10*28
8	91000-08035B	4	HEX SOCKET BOLT	8*35
9	53165-302-000	1	R. HANDLE GRIP	
10	53166-302-000	1	L. HANDLE GRIP	
11	22870-501-000	1	CLUTCH CABLE	
12	88120-145-000	1	L.REAR VIEW MIRROR	
13	88110-145-000	1	R.REAR VIEW MIRROR	
14	35345-169-000	1	L.CLUTCH SWITCH	
15	17950-501-000	1	CHOKE CABLE	
16	53179-501-00A	1	LEFT LEVER ASS'Y	
17	43480-501-001	1	REVERSE CABLE A	
18	35200-169-00A	1	L.HANDLE SWITCH ASS'Y	
19	37210-302-000	1	SPEEDOMETER BRACKET	
20	35210-501-000	1	REVERSE SWITCH	
21	94101-0614020B	1	PLAIN WASHER	6*14*2

501-F13B STEERING

FRONT




501-F13B

(EU2)STEERING

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	91331-179-000	2	O-RING	
2	51114-169-000	2	HOLDER SPACER COLLER	10*14.2*50
3	51113-169-000	2	STEERING SHAFT HOLDER	
4	44520-169-000	1	RIGHT KNUCKLE ASS'Y	
5	44510-169-000	1	LEFT KNUCKLE ASS'Y	
6	96000-10065-14G	2	HEX FLANGE BOLT	M10*65
7	45451-501-000	1	BRACKET	
8	94512-4000R	1	INTERNAL CIR CLIP	RTW-40
9	96500-274008	1	OIL SEAL	27*40*8
10	96100-6203ZZ	1	RADIAL BALL BEARING	6203ZZCS05/2A
11	51120-169-000	1	STEERING SHAFT BUSHING	14.5*22*13
12	96500-22357	1	OIL SEAL	22*35*7
13	90350-14000G	1	NYLON NUT	M14
14	94201-30320B	4	COTTER PIN	3*32
15	44511-256-0A0	2	BALL JOINT,LEFT THREAD	
16	44521-256-0A0	2	BALL JOINT,RIGHT THREAD	
17	94001-12000LC	2	HEX NUT	M12
18	91001-12356B	2	ROD	M12*356
19	94001-12000B	2	HEX NUT	M12
20	94101-1020020G	4	COPPER PLAIN WASHER	10*20*2
21	90350-10000G	4	NYLON NUT	M10*P1.25
22	94201-20190B	4	COTTER PIN	2*19
23	96421-197-000	1	RUBBER CAP	
24	37200-501-001	1	SPEEDOMETER ASS'Y	
25	37218-225-000	1	SENSOR	
26	37217-256-000	1	MAGNET	(M6)
27	91000-05016	2	HEX SOCKET BOLT	5*16
28	96403-0507011	3	SPACE TUBE	5*7*10.8
29	94101-0514010K	3	PLAIN WASHER	5*14*1
30	37202-225-000	3	DAMPER	
31	94056-05000B	3	SELF LOCKING RING	5mm

501-F14A BATTERY & MAIN WARNISS AS




501-F14A

(EU2) BATTERY &amp; MAIN WARNES;S'Y

Item No.	Parts No.	Unit Q'ty	Parts Name		
1	31600-501-000	1	REGULATER RECTIFIER		
2	96000-06016-10G	2	HEX FLANGE BOLT	6*16	
3	32100-501-00A	1	WIRE HARNESS		
4	17620-169-00C	1	FUEL CAP (W/LOCK)		
5	81142-261-000	3	INNER BOX LOCK		
6	31504-169-000	1	BATTERY COVER		
7	32105-501-000	1	SUB. HARNESS		
8	32108-912-000	1	POSITIVE CABLE		
9	94055-06000C	4	HEX FLANGE NUT WITH SERRATION(TOOTH)		
10	38501-501-000	1	STARTER SOLENOID		
11	98200-912-000	1	FUSE	20A	
12	16148-501-000	1	CARBURETOR REDUCER		26,5
13	31500-225-000	1	Battery	WP 12-B	
14	30003-169-000	1	RUBBER PAD		
15	31520-169-000	1	BATTERY STRAP		
16	32103-169-0A1	1	GROUND WIRE		
17	96000-06010-10G	2	HEX FLANGE BOLT	M6*10	
18	94115-0611006	1	EXT. TOOTHED LOCK WASHER	6*11*0.6	
19	35010-225-00A	1	KEY SET		
20	35100-223-00A	1	MAIN SWITCH		
21	53600-223-000	1	STEERING HANDLE LOCK		
22	93902-06012BL	2	FLAT HEAD PHILLIPS BOLT	6*12	
23	35102-145-000	1	MAIN SWITCH BRACKET		
24	38301-107-0AC	1	FLASHER RELAY	12V 40W	
25	38110-256-000	1	HORN	CL-2	
26	35350-108-000	1	STOP SWITCH ASS'Y		
27	35357-501-000	1	STOP SWITCH SPRING		
28	90669-101-000	6	CABLE TIE	4.8*200 m/m	
29	90669-101-00A	2	CABLE TIE	4.8*250m/m	
30	90669-218-000	2	CABLE TIE	3.6*330 m/m	
31	35101-223-000	1	KEY(L)		
32	32116-501-000	1	EXTENSION WIRE		

501-F15A SIGNAL LIGHT,TALE LIGHT



501-F15A

(EU2) SIGNAL LIGHT,TALL LIGHT

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	33100-225-000	1	HEAD LIGHT ASS'Y	EC
2	34901-190-00B	1	HEAD LIGHT BULB	12V35W35W
3	34909-169-000	1	POSITION LAMP	12V5W
4	93903-05016K	2	TAPPING SCREW TRUSS HEAD PH 5*16	
5	94101-0618020B	2	PLAIN WASHER	6*18*2
6	33400-501-000	2	R.SIGNAL ASS'Y (E-MARK)	W020-FR-A022
7	93500-03010C	8	PAN PHILLIPS BOLT	3*10
8	34905-118-00A	4	BULB(E-MARK)	12V/10W
9	33425-501-000	2	SIGNAL BULB SOCKET	
10	33413-501-000	4	SIGNAL RUBBER WASHER	
11	33450-501-000	2	L.SIGNAL ASS'Y(E-MARK)	W020-FL-A022
12	33435-501-000	2	L.SIGNAL BULB SOCKET	
13	94050-05000C	4	HEX FLANGE NUT WITH SERRATED	5mm
14	33700-225-000	1	TAIL LIGHT ASS'Y	E-MARK
15	90350-06000G	2	NYLON NUT	M6
16	33401-501-000	4	SIGNAL SOCKET	
17	33403-225-000	4	FIX BRACKET	
18	94101-0514010K	8	PLAIN WASHER	5*14*1
19	93903-04016K	2	TAPPING SCREW TRUSS HEAD PH 4*16	
20	34801-225-000	1	HEAD LIGHT WIRE	

501-F16A STICKER

**WARNING**

Improper tire pressure or over-loading can cause loss of control, resulting in SEVERE INJURY or DEATH. ALWAYS maintain proper tire pressure as shown.

NEVER set the pressure below minimum. It could cause the tire to dislodge from the rim.

NEVER exceed the vehicle load capacity of 168kg (371lb) including weight of operator, cargo, accessories and trailer tongue weight.

**ATV LOADING and TRAILER TOWING**  
Cargo loading or trailer towing can affect stability and handling.

- reduce speed.
- allow more distance to stop.
- avoid hills, rough terrain.

COLD TIRE PRESSURE	
FRONT/REAR	Pressure: 10 psi (0.7 kgf/cm <sup>2</sup> )
	Max.: 15 psi (1.05 kgf/cm <sup>2</sup> )
	Min.: 3.5 psi (0.245 kgf/cm <sup>2</sup> )

87756-169-00A

**WARNING**

**UNDER 16**

Operating this ATV if you are under the age of 16 increases your chance of SEVERE INJURY or DEATH. NEVER operate this ATV if you are under age 16.

87756-169-00B

HER CHEE INDUSTRIAL CO., LTD.

e \_\_\_\_\_

\_\_\_\_\_

dB(A)- \_\_\_\_\_ min \_\_\_\_\_

**WARNING**

Improper ATV use can result in SEVERE INJURY or DEATH.

 **ALWAYS USE AN APPROVED PROTECTIVE GEAR.**

 **NEVER USE WITH DRUGS OR ALCOHOL.**

**NEVER operate:**

- without proper training or instructions.
- at speeds too fast for your skills or the conditions.
- Do not make turns with high speed to avoid turn over.

**ALWAYS:**

- use proper riding techniques to avoid vehicle overturns on hills and rough terrain and in turns.
- avoid paved surfaces; pavement may seriously affect handling and control.
- ALWAYS WEAR HELMET and other protection equipment.
- Shut off engine when refill gasoline.
- Read owner's manual before riding and always keep the owner's manual with vehicle.

LOCATE AND READ OPERATOR'S GUIDE. FOLLOW ALL INSTRUCTIONS & WARNINGS.

87756-169-00C


**DRIVE CHAIN**

DRIVE CHAIN MUST BE WELL ADJUSTED AND LUBRICATED. FREE PLAY IS 20-30 mm (0.8-1.2 in) WITH DRIVER NOT ON VEHICLE. SEE OWNER'S MANUAL FOR COMPLETE INSTRUCTIONS.

20-30 mm (0.8-1.2 in)



87756-169-00D




7

501-F16A

STICKER

Item No.	Parts No.	Unit Q'ty	Parts Name
1	87700-888-00Z	1	ADLY POLY STICKER
2	87756-169-00A	1	WARNING LABEL(TIRE INFLATION)
3	87758-169-00A	1	WARNING LABLE(INJURE)
4	87759-169-000	1	WARNING LABLE(16 YEARS OLD AND UNDER)
5	87739-179-000	1	CHAIN INSTRUCTION DECAL
6	50110-101-001	1	I.D PLATE 80*35
7	87700-501-000	1	STICKER ASS'Y

FRONT




501-F18

## COOLING SYSTEM

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	19000-501-000	1	RADIATOR ASS'Y	
2	35510-501-000	1	FAN SWITCH	
3	19120-501-000	1	RADIATOR FAN ASSY	
4	19100-501-000	1	RADIATOR BODY	
5	19110-225-000	1	RADIATOR CAP	
6	19113-501-000	1	FILL NECK	
7	19109-501-000	1	HOSE LONNECTER	
8	19107-501-000	1	HOSE RAD. IN	
9	19102-501-000	1	HOSE RAD. OUT	
10	94516-27000	2	CLAMP	#27.5(1 1/16")
11	19200-179-000	1	COOLANT TANK	REV.A
12	19201-179-000	1	TANK ANCHOR	
13	92006-06014-10G	9	HEX WASHER FACE BOLT	6*14
14	19210-179-000	1	COOLANT TANK CAP	
15	19211-179-000	1	CAP PROTECTOR	
16	19106-179-000	1	GROMMET	
17	19220-179-000	1	MALE CONNECTOR	
18	94400-0609300	1	HOSE	6*9*300
19	94513-08000	1	SPRING CLAMP	
20	96000-06012-10G	4	HEX WASHER FACE BOLT	6*12
21	90350-06000G	4	NYLON NUT	M6
22	94101-0618020K	2	PLAIN WASHER	6*18*2
23	50114-501-000	1	RIGHT LEFE	
24	50135-501-000	1	RADIATOR BRACKET	
25	94400-0609070	1	HOSE	6*9*70
26	92000-06025-10K	4	HEX BOLT	6*25
27	19117-501-000	1	RADIATOR COWLING L.	
28	19118-501-000	1	RADIATOR COWLING R.	
29	94514-38000	4	CLAMP	
30	19202-501-000	1	COOLANT TANK BRACKER	
31	19121-501-000	1	COWLING BRACKET R.	
32	19122-501-000	1	COWLING BRACKET L.	
33	92006-06012-10K	6	HEX WASHER FACE BOLT	6*12
34	94513-09000	1	SPRING CLAMP	

501-C03 ACCESSORY



501-C03

(EU2)ACCESSORY(EU2)

Item No.	Parts No.	Unit Q'ty	Parts Name	
1	50100-501-000BK	1	FRAME	
2	50104-225-00ABK	1	FRONT BUMPER	
3	50105-225-001BK	1	REAR BUMPER	
4	51200-501-00ABK	1	R. UPPER SUSPENSION ARM	
5	51300-501-00ABK	1	L. UPPER FRONT ARM	
6	51600-501-000BK	1	R. LOWER FRONT ARM	
7	51500-501-000BK	1	L. LOWER FRONT ARM	
8	64301-903-000BK	1	FRONT COVER	
9	83400-501-001BK	1	REAR COVER	
10	51109-901-001BK	1	STEERING SHAFT ASS'Y (BK)	
11	64339-225-000BK	1	FRONT LUGGAGE BOX COVER	
12	83417-225-000BK	1	L. REAR LUGGAGE BOX COVER	
13	83418-225-000BK	1	R. REAR LUGGAGE BOX COVER	
14	90350-06000G	2	NYLON NUT	M6
15	77201-169-000	1	SEAT LATCH	
16	77200-225-001	1	SEAT ASS'Y(BK/SL)	ADLY
17	52100-501-002BK	1	SWING ARM SUB ASS'Y	
18	53100-302-000BK	1	HANDLE BAR	